



5411 Seymour Hwy Wichita Falls, TX 76301

Tel: 940-767-7694 Fax: 940-687-0751

WWW.NITROUSEXPRESS.COM

Purge Valve Push Lock part number 15598

Caution – EXTREME DANGER – Caution

Do not use or mix any other manufacturer's products with any Nitrous Express products.

Do not use or mix any Nitrous Express product's with any other manufacturer's products.

THESE INSTRUCTIONS APPLY TO NITROUS EXPRESS PRODUCTS ONLY!

FOR SANCTIONED RACE USE ONLY – NOT FOR SALE OR USE IN CALIFORNIA


The installation of this purge valve will add to the value, consistency, and performance of your NX system. The purpose of the purge is to remove all gaseous nitrous and air from your main feed line. This puts liquid nitrous at the N₂O solenoid resulting in a harder leave or "hit".

Before you begin make sure that your bottle valve is closed and your main feed line is empty. Liquid nitrous can cause severe frostbite if it comes in contact with your skin! Use NX liquid thread sealer on any NPT fittings. Never use Teflon tape on any fittings of a nitrous system. AN fittings do not require sealer of any kind.

If your solenoid has a purge port, follow the instructions and diagram in Section A. If your Nitrous Solenoid does not have a purge port, skip to Section B.


Section A – Installation with N₂O solenoids that have a purge port. (NX Lightning and Iceman Series Solenoids.)

1. Using the supplied union fitting, connect the inlet of the purge solenoid to the purge port of the N₂O solenoid.
2. Plug the purge port of the purge solenoid with the supplied Allen Head Pipe plug.
3. Connect the 1/8NPT to Push Lock fitting into the N₂O out port on the purge solenoid.
4. Insert the Soft Line into the Push Lock fitting and make sure it's secured.
5. Run the Soft Line in the route you would want the nitrous to be purged out of the engine compartment. The preferred venting is at the windshield base so the nitrous flow can be viewed from the driver's seat.
6. Skip to Section C.



Section B – Installation with N2O solenoids that do not have a purge port. (NX Mainline solenoids or other solenoids that lack a purge port)

1. Disconnect the feet line from the N2O solenoid.
2. Install the AN adapter manifold between the N2O feed line and the N2O solenoid inlet.
3. Using the supplied union fitting, connect the inlet of the purge solenoid to the 1/8NPT port on the side of the AN adapter manifold.
4. Plug the purge port of the purge solenoid with the supplied Allen Head pipe plug.
5. Connect the 1/8NPT to Push Lock fitting into the N2O out port on the purge solenoid.
6. Insert the Soft Line purge into the push lock fitting and make sure it is secure.
7. Route the Soft Line in a direction that will purge the nitrous out of the engine compartment. The preferred venting is at the windshield base so the nitrous flow can be viewed from the driver's seat.
8. Continue to Section C



Section C – Wiring and Testing

1. Wiring the purge valve is easy but care must be taken. One of the two wires on the solenoid will go to ground, the other will attach to your push button. The other terminal on the push button will go to the output of your master arming switch.
2. TESTING: Slowly open the bottle valve. Now is the time to check for leaks, if any are seen or heard tighten the fitting that is leaking.
3. Turn the arming switch on and push the purge activation button; you should hear a click and see liquid (white) N₂O coming from the vent line.
4. Now you are ready to use your new NX purge.

NOTE: The nitrous and fuel solenoids are rated only for intermittent duty. Do not engage either solenoid for more than 20 continuous seconds. Solenoids that have “burned or scorched” electro-magnets will not be replaced under warranty.